How to update the NGRM

NGRM500   NGRM550   NGRM700   NGRM750

2024-April-10   BU-I-PD   Matthias Oehler

What you need

- PC with ethernet connection

- appropriated update file

- connect the NGR-Monitor and the PC with the ethernet cable

- open the web server with the IP address of your device

- default address is 192.168.0.5

First step

Restart the NGR-Monitor by removing the power supply for at least 3 s

After reboot go ahead

Select and update

open the WEB Server

select "Tools" – "Update"

and select the file for the specific NGR-Monitor

each NGR-Monitor derivate has its own update file

Enable the update

If the update is denied, enable the update via the NGR-Monitor menu and press "Back" in the web browser

Upload

Press upload and
wait until the file is
completely uploaded

Update

press update

During the update, the progress can be followed on the device display

Check update

After the update is complete, please check the versions

On the device press the INFO button, or navigate to Menu\Info\Software

Releases April 2024

Device	Interface Unit		Measurement Unit		Bender Update File
	D Number	Release	D Number	Release	BUF
NGRM500	D0618	V2.10	D0510	V4.00	06180013.buf
NGRM550	D0728	V1.10	D0510	V4.00	07280007.buf
NGRM700	D0511	V3.10	D0510	V4.00	05110018.buf
NGRM750	D0726	V1.10	D0510	V4.00	07260007.buf

Only for devices in stock

Only for **devices in stock**, the history can be deleted and the settings can be load to defaults.

Skip this steps for devices in a field application!

- delete history

- load default settings

- turn off device

Matthias Oehler

Bender GmbH & Co. KG
Business Unit Industrial Solutions

Product Development